



LLF[™]
Light Reinvented.[™]

Can Compatibility Testing Results: LR6

As of August 24, 2007

Manufacturer	Size	Nomenclature	Compatible as is	Compatible with mod's	Modification	Can Dia.	Can Depth
Halo - A	6"	H7ICT	No	Yes	Remove "L" bracket and backing plate. Unclip Edison socket from backing plate.	6	6
	6"	H7ICTNB	Yes	X	Compatible as is	6	6
	6"	H7ICAT	No	Yes	Remove "L" bracket and backing plate. Unclip Edison socket from backing plate.	6	6
	6"	H7ICATNB	Yes	X	Compatible as is	6	6
	6"	H7T	Yes				
	6"	H7TNB	X	X	Not available. Same as H7ICT without L bracket.		
	6"	H7RICAT	No	Yes	Remove "L" bracket and backing plate. Unclip Edison socket from backing plate.	6	6
	6"	H7RICT	No	Yes	Remove "L" bracket and backing plate. Unclip Edison socket from backing plate.	6	6
	6"	H7RT	No	Yes	Remove "L" bracket. Unclip Edison socket from backing plate.	6	6
	6"	H7UICAT	No	No	Can too shallow	6	5.5
	6"	H7UICT	No	No	Can too shallow	6	5.25

Lithonia - A	6"	LC6	Yes	X	Compatible as is	6.75	7.75
	6"	L7X	Yes	X	Compatible as is	6.75	7.75

Juno - A	6"	IC2	No	Yes	Loosen two socket bracket screws and turn socket bracket to free it. Bend side tabs down slightly.	6.5	7 1/8
----------	----	-----	----	-----	--	-----	-------

	6"	IC2W	No	Yes	Loosen two socket bracket screws and turn socket bracket to free it. Bend side tabs down slightly.	6.5	7 1/8
	6"	TC2	No	Yes	Loosen two socket bracket screws and turn socket bracket to free it. Bend side tabs down slightly.	6.25	7.25
	6"	TC2R	No	Yes*	Loosen socket bracket screw and turn socket bracket to free it. Bend side tabs down slightly. *Can depth must be set > 6".	6.25	Variable
	6"	TC2W	No	Yes	Loosen two socket bracket screws and turn socket bracket to free it. Bend side tabs down slightly.	6 3/8	7 1/8
	6"	IC22	No	Yes	Must remove socket bracket. In this can, it requires the removal of two screws.		
	6"	IC22R	No	Yes	Loosen socket bracket screw and turn socket bracket to free it. Bend side tabs down slightly. Loosen backing plate slide nuts. Pry backing plate slide over slide stops. Bottom out backing plate.	6.5	6.75
	6"	IC22W	No	Yes	Loosen socket bracket screw and turn socket bracket to free it. Bend side tabs down slightly. Loosen backing plate slide nuts. Pry backing plate slide over slide stops. Bottom out backing plate.	6.5	6.75
	6"	IC23	No	Yes	Loosen socket bracket screw and turn socket bracket to free it. Bend side tabs down slightly.	6.5	7
	6"	IC23R	X	X	Does not exist. See IC22R.		

Progress - A	6"	P87-AT	No	Yes	Must remove Edison socket from spring clips. Spring clips must then be bent back into the can. Cutting spring clips is another option.	6.5	6.75
	6"	P87-ATQC	No	Yes	Must remove Edison socket from spring clips. Spring clips must then be bent back into the can. Cutting spring clips is another option.	6.25	6.75
	6"	P187-TG	No	Yes	Must remove Edison socket from spring clips. Spring clips must then be bent back into the can. Cutting spring clips is another option.	6.25	6.75
	6"	P821-AT	No	Yes	Must remove Edison socket from spring clips. Spring clips must then be bent back into the can. Cutting spring clips is another option. Refelctor can be left in place.	6.5	6.75

Lightolier - B	6"	C6AIC	X	X	Not recessed can		
	6"	C6120	X	X	Not recessed can		
	6"	C6A120	X	X	Not recessed can		
	6"	C6DAIC	X	X	Not recessed can		
	6"	C6D120	X	X	Not recessed can		
	6"	C6DA120	X	X	Not recessed can		
	6"	1104IC	No	Yes	Remove socket assembly from can. Bend short clips back. Leave the long clips as is. Screw LLF fixture into Edison socket and fully extend LLF retaining clips. Push assembly into can and turn 1/4 turn. To remove fixture, unscrew from Edison socket.	6.75	6.5

	6"	1104ICN	No	Yes	Remove socket assembly from can. Bend short clips back. Leave the long clips as is. Screw LLF fixture into Edison socket and fully extend LLF retaining clips. Push assembly into can and turn 1/4 turn. To remove fixture, unscrew from Edison socket.	6.75	6.5
	6"	1104ICR	No	Yes	Remove socket assembly from can. Bend short clips back. Leave the long clips as is. Screw LLF fixture into Edison socket and fully extend LLF retaining clips. Push assembly into can and turn 1/4 turn. To remove fixture, unscrew from Edison socket.	6.75	6.5
	6"	1104ICX	No	No	No sidewall		
	6"	1104ICXN	No	No	No sidewall		

Capri - B	6"	CR1	No	Yes	Remove L bracket and unclip Edison socket	6.25	6.5
	6"	CR1QP	No	Yes	Remove L bracket and unclip Edison socket	6	6.5
	6"	CR1NB	Yes	X	Compatible as is	6.25	6.5
	6"	CR1NBQP	Yes	X	Compatible as is	6.25	6.5
	6"	PR1	No	Yes	Remove L bracket and unclip Edison socket	6	6.5
	6"	PR1QP	X	X	Does not exist		
	6"	CRR1	No	Yes	Remove L bracket and unclip Edison socket	6	6.5
	6"	CRR1QP	No	Yes	Remove L bracket and unclip Edison socket	6.25	6.5
	6"	CRR1NB	Yes	X	Compatible as is	6	6.5
	6"	CRR1NBQP	Yes	X	Compatible as is	6.25	6.5
	6"	QL1	No	Yes	Remove L bracket and unclip Edison socket	6	6.5
	6"	QL1QP	No	Yes	Remove L bracket and unclip Edison socket	6	6.5
	6"	QL1NB	Yes	X	Compatible as is	6	6.5
	6"	QL1NBQP	Yes	X	Compatible as is	6.25	6.5

	6"	R150ASIC	No	Yes	Remove L bracket and unclip Edison socket	6	6
	6"	CIND6	No	Yes	Remove L bracket and unclip Edison socket	6	9

Emerald - B	6"	P101-ICW			Bought by Cooper Ligting - not available		
	6"	P301-ICW			Bought by Cooper Ligting - not available		
	6"	P301-ICWW			Bought by Cooper Ligting - not available		

Seagull - B	6"	1119	No	No	Can too shallow.	6	5.5
	6"				Remove socket bracket wingnut and screw. Remove socket bracket. Unclip Edison socket from bracket.	6	7.75
	6"	1128QC	No	Yes	Remove socket bracket wingnut and screw. Remove socket bracket. Unclip Edison socket from bracket.	6	6
	6"	1107	No	Yes	Remove socket bracket wingnut and screw. Remove socket bracket. Unclip Edison socket from bracket.	6	6.75
	6"	1108	No	Yes	Remove socket bracket wingnut and screw. Remove socket bracket. Unclip Edison socket from bracket.	6	7.75
	6"	1128	No	Yes	Remove socket bracket wingnut and screw. Remove socket bracket. Unclip Edison socket from bracket.	6	7.75
	6"	1118	No	Yes	Remove socket bracket wingnut and screw. Remove socket bracket. Unclip Edison socket from bracket.	6	7.75